

Instructions for the safe use of power cords.

The document refers to the EU Regulation 2023/988 on General Product Safety (GPSR)

1. Before use, make sure that the power cord is not damaged. Check the cords, plugs and sockets for cracks, abrasions or other damage - never use a damaged cord.
2. Use power cords in accordance with the specifications.

Do not exceed the maximum load.
3. Use cords intended for indoor use only in covered rooms.
4. External cords should be weatherproof - in accordance with the declared degree of protection (IP).
5. Make sure that the devices you connect to the cord are switched off.
6. Do not connect devices requiring grounding to ungrounded cords.
7. Avoid contact of the power cord with water. Use it in dry places and avoid placing it near water sources. If using an extension cord outdoors, make sure that it is not raining or there is no moisture.
8. The power cord should be stored in dry rooms, away from heat sources and in places where it will not be exposed to direct sunlight.
9. Warranty and post-warranty service is provided by the manufacturer.
10. Used cables must not be disposed of with regular waste. It is the user's responsibility to transfer used equipment to a designated collection point for proper processing.

IT IS PROHIBITED: attempting to open, repair or modify power cords yourself.

Following these rules will help ensure safety when using the power extension cord.

Neither the manufacturer nor the seller is responsible for improper use of the products.

